

Bin	H_T^{miss} [GeV]	H_T [GeV]	$N_{\text{b-jet}}$	$pp \rightarrow \tilde{g}\tilde{g}, \tilde{g} \rightarrow \text{bb}\tilde{\chi}_1^0$	$pp \rightarrow \tilde{g}\tilde{g}, \tilde{g} \rightarrow \text{tt}\tilde{\chi}_1^0$	$pp \rightarrow \tilde{g}\tilde{g}, \tilde{g} \rightarrow \text{qq}\tilde{\chi}_1^0$
				$m_{\tilde{g}} = 1500 \text{ GeV}$ $m_{\tilde{\chi}_1^0} = 100 \text{ GeV}$	$m_{\tilde{g}} = 1500 \text{ GeV}$ $m_{\tilde{\chi}_1^0} = 100 \text{ GeV}$	$m_{\tilde{g}} = 1000 \text{ GeV}$ $m_{\tilde{\chi}_1^0} = 800 \text{ GeV}$
49	200-500	500-800	0	0.00 ± 0.00	0.00 ± 0.00	0.87 ± 0.11
50	200-500	800-1200	0	0.00 ± 0.00	0.01 ± 0.00	1.99 ± 0.16
51	200-500	1200+	0	0.04 ± 0.00	0.09 ± 0.00	0.80 ± 0.10
52	500-750	500-1200	0	0.00 ± 0.00	0.01 ± 0.00	0.49 ± 0.08
53	500-750	1200+	0	0.04 ± 0.00	0.07 ± 0.00	0.66 ± 0.09
54	750+	800+	0	0.03 ± 0.00	0.06 ± 0.00	0.64 ± 0.09
55	200-500	500-800	1	0.00 ± 0.00	0.00 ± 0.00	0.29 ± 0.04
56	200-500	800-1200	1	0.00 ± 0.00	0.03 ± 0.00	0.81 ± 0.07
57	200-500	1200+	1	0.15 ± 0.01	0.37 ± 0.01	0.33 ± 0.05
58	500-750	500-1200	1	0.00 ± 0.00	0.02 ± 0.00	0.16 ± 0.03
59	500-750	1200+	1	0.13 ± 0.01	0.32 ± 0.01	0.27 ± 0.04
60	750+	800+	1	0.11 ± 0.01	0.25 ± 0.01	0.28 ± 0.04
61	200-500	500-800	2	0.00 ± 0.00	0.00 ± 0.00	0.05 ± 0.01
62	200-500	800-1200	2	0.01 ± 0.00	0.05 ± 0.00	0.20 ± 0.03
63	200-500	1200+	2	0.22 ± 0.01	0.61 ± 0.01	0.09 ± 0.02
64	500-750	500-1200	2	0.00 ± 0.00	0.04 ± 0.00	0.03 ± 0.01
65	500-750	1200+	2	0.19 ± 0.01	0.53 ± 0.01	0.07 ± 0.02
66	750+	800+	2	0.16 ± 0.01	0.41 ± 0.01	0.09 ± 0.02
67	200-500	500-800	3+	0.00 ± 0.00	0.00 ± 0.00	0.01 ± 0.00
68	200-500	800-1200	3+	0.01 ± 0.00	0.06 ± 0.00	0.04 ± 0.01
69	200-500	1200+	3+	0.22 ± 0.01	0.77 ± 0.02	0.01 ± 0.00
70	500-750	500-1200	3+	0.00 ± 0.00	0.04 ± 0.00	0.00 ± 0.00
71	500-750	1200+	3+	0.20 ± 0.01	0.67 ± 0.02	0.01 ± 0.00
72	750+	800+	3+	0.16 ± 0.01	0.49 ± 0.01	0.02 ± 0.01